



Mount the sockel with the 4 pcs. of corners. Place the crosses in the sockel. Size 100x200 cm. has 2 sets of crosses Size 140/160/180x200 cm. & 180x210 cm. have 4 sets of crosses. Size 180x220 + 200x200/210/220 cm. have 6 sets of crosses.



Put the underpart/boarder of the ticking on the bottomplate, and put the foam inside the boarder.





Place the bottomplate on top of the sockel.



4.

Place the heater (heaters if dual mattresses) on the bottomplate. The picture shows how to place the heaters if it's a dual mattress. But if it's an uno mattress, please the heater in the middle.



Telefon: +45 58 55 01 00 Telefax: +45 58 55 01 01 E-mail: info@wacore.dk CVR-nr.: 21 20 31 49







Put the safety liner around the foam. The black thing on the picture is the divider, which is placed between a set of dual mattresses.



Zip the top on the boarder, and you are finished building up your Softside.

E-mail: info@wacore.dk

CVR-nr.: 21 20 31 49



Place the mattress(es) in the foam, and make sure that the corners of the mattress comes fully out to the corners of the foam. It's also very important that there are no folds underneath the mattress.

Fill the mattress with lukewarm water (not hot water).

After filling the mattress, use the airextractor to take the air out.

Telefon: +45 58 55 01 00

Telefax: +45 58 55 01 01

